

603/604: Industry Pro Female Dressmaker Form

Installation Guide

Please find the following items in your box. If anything is missing or damaged, contact your dealer immediately.

- BASE 1 pc.
- SPRING 1 pc.
- INNER POLE 1 pc.
- OUTER POLE 1 pc.
- DRESS FORM 1 pc.
- TOPPER 1 pc.



Inner Pole



Outer Pole



Dressmaker

Form



Base

Topper



Spring



Finial /


Step 1

Please place the base firmly on a flat surface.



Step 2

Insert the inner pole into the base **ALL THE WAY THROUGH** and push it in firmly. The bottom of the pole should sit on the disc at the end of the foot pedal.



IMPORTANT:


After you have successfully inserted the inner pole into the base, **please tighten the eye-bolt using a tool such as screw driver to help you.** Insert the screw driver or any other tools through the ring of the eye-bolt, and then turn it as hard as you can. **Make sure eye-bolt is screwed in tight.**

Step 3

After the inner pole is tightened into the base, you can now step on the foot pedal.




While you are stepping on the foot pedal, please check that the top of the inner pole is aligned together.



Step 4:

While you are stepping down on the foot pedal, you should see that the top of the inner is aligned. At this time, slip the spring over the pole and then slide the outer pole on. While you are still stepping down on the foot pedal, you can now slide the outer pole over the inner pole.



Step 5:

After you have successfully put the outer pole on, now you can put your dress maker form on. Please note that the top of the outer pole is supposed to be bent slightly as this allows for the dressmaker form to sit at the correct angle along with the finial piece.



The top of the outer pole with the nail is supposed to fit through the hole on the top of the dressmaker form.

FINAL STEP:

Now you can put the finial / topper piece on, and you are done!

Step on the pedal to adjust the height of the dressmaker form.



Topper